



**Figure 2F-10. Sign convention for the measured angle ( $\theta$ ) when the probe impact port is pointed directly into the flow. The angle  $\theta$  is positive when the probe's impact pressure port is oriented in a clockwise rotational position relative to the stack or duct axis, as shown above and negative for a counterclockwise orientation.**